# **ROTRONIC MANUAL**

# BF227 Digital Pressure Transmitter

## **Instruction Manual - Communication Protocol**





# Inhaltsverzeichnis

1	Communication Protocol	3
2	Detailed Rules	4
_		
3	Communication	4

## 1 Communication Protocol

Data Format: 1 start bit, 8 data bit, 1 stop bit, no parity bit. Instruction Format

#### 1. Send Instruction:

\$	XX	YY	[S #. ###]	PP	Chr (13)
Start character	Address	Instruction	Parameter	Check	End character

#### 2. Answer:

*	XX	[S#.###]	PP	Chr (13)
Start character	Address	Parameter	Check	End character

Instruction explanation: The instruction format is flexible, contents in brakets "[]" are optional.

\$	Start character of sending instruction, 1 byte, ASCII code is 24H						
*	Start character of answering instruction, 1 byte, ASCII code is 2AH						
Return	End character of instruction, 1 byte, ASCII code is 0DH						
xx	Address mark, 2 bytes, from 01 to 99, totally 99 optional addresses and one						
	omnipotent address 00						
YY	Instruction code, 2 bytes, composed by capital letter, details to see detailed						
S	"+" or "-", 1 byte						
	Decimal, 1 byte, in the middle of the number, could be changed due to						
	different units						
####	Number, 4 bytes, algorism						
	Check character, 2 bytes; PP valve could be got from one byte which will be						
PP	calculated (XOR) by ASCII between start character and check character one bit						
	by one bit; the byte's high and low nibbles are indicated by ASCII, therefore,						

#### > Special Indication

Address "00" is universal address. When user inputs "00" address, please be sure there is only one transmitter in the bus line. Otherwise, bus line transmitters will compete with each other, and this will result in wrong return value.

## 2 Detailed Rules

The usage of detailed rules on the following table, take transmitter parameter as example:

Address: 55

Baud Rate: 9600bps

SN: 02461232

Transmitter: -0,1...1MPa

Temperature: 25°C

Current Pressure: 0.500MPa

Pressure Type: Absolute

Software Version: V1.00

## 3 Communication

In the following table, check character and end character have been omitted. When using, the instruction could be valid by adding these two characters.

Instruction	Details	Parameter	Instruction	Answer	Comments	
instruction			Example	Example	Comments	
AD	Read address		\$00AD	*5555	Parameter range is number 01, 00	
AD	Write address	##	\$55AD34	*3434	Parameter range is number 01~99.	
BD	Read baud rate		\$55BD	*551	Parameter 0,1,2,3 could be optional, stands for	
ВО	Write baud rate	#	\$55BD1	*551	1200,2400,4800,9600 bps respectively	
RP	Read transmitter pressure value	#	\$55RP0	*55+0.500	#:channel No., the ranges are different according to different transmitter types	
ID	Read SN		\$55ID	*550246123 2	SN is 02461232	
DL	Read zero display		\$55DL	*55-0.100		
	Setup zero display	S#.###	\$55DL-0.100	*55-0.100		
DH	Read FS display		\$55DH	*55+1.000		
DIT	Setup FS display	S#.###	\$55DH+1.000	*55+1.000		
	Read zero transmitting Output		\$55OL	*55-0.100		
	Read zero transmitting Output	S#.###	\$55OL-0.100	*55-0.100		
	Read FS transmitting output		\$55OH	*55+1.000		
	Read FS transmitting output	S#.###	\$55OH+1.00 0	*55+1.000		
DP	Read decimal position		\$55DP	*553	Parameter range is 0, 1, 2, 3 and 4, display integer correspondingly, 1, 2, 3, or 4 decimals	
DF	Setup decimal position	#	\$55DP3	*553		

## **BF227 – Digital Pressure Transmitter**



E-M-BF227-V1\_00.docx

**Instruction Manual** 

WU	Save setting value to user		\$55WU	*55OK	OK means save successfully.			
LD	Restore factory setting		\$55LD	*55OK	OK means save successfully.			
UT	Read transmitter unit		\$55UT	*551	Returning value range is 0, 1, 2, 3, 4 and 5, means kPa, MPa, mH <sub>2</sub> O, bar, Psi, mbar respectively			
SZ	Zero		\$55SZ	*55OK	OK means save successfully			
ZF	Read zero final		\$55ZF	*55+1224	Parameters are 4 algorism numbers with symbol			
2.	Setup zero final	S####	\$55ZF+1233	*55+1233	Parameters are 4 algorism numbers with symbol			
FF	Read FS final		\$55FF	*55+3453				
"	Setup FS final	S####	\$55FF+3244	*55+3244	Parameters are 4 algorism numbers with symbol			
					Type code Type Output Channel Reserve			
					#######################################			
	Read type	•		*55460-1000	4 6 0 0 Gauge 0 No output 0			
TY	Pressure type		\$55TY		4 6 2 E Sealed 1 4-20mA Single Ochannel			
	Output type	φσσ	00.00.1000	4 6 2 B 1 gauge 2 0-10mA 0 channel 0				
			4 8 4 A 2 Absolute 3 0-20mA Double 0					
			4 8 4 Z 3 Differential 4 0-5V 1 Double channel 0					