

RS-485 MASTERBOX



RS-485/ETHERNET CONVERTER.

- Enables connection of 64 RS-485 slaves to an Ethernet network
- Masterbox has its own changeable IP-Address
- Possibility to combine AirChip 3000 devices with devices of the previous generation in the same RS-485 network
- Configure the Masterbox with the ROTRONIC HW4 Software
- Wall or DIN rail mounting
- HF5 housing



TECHNICAL INFORMATION

Housing material	ABS
IP protection	IP65
Dimensions	129 x 72 x 45 mm
Weight	200 g
Display	No
Electrical connection	Ethernet: RJ-45 / RS-485: screw terminals
Power Supply	12...24 VDC
Current consumption	85 mA
Operating range	-40...70 °C / 0...100 %rF
Standards	CE-compliant 2007/108/EG
Order code	AC3011

Installation in the RS-485 Network

